

February 2012

Artikel-Nr.: 10022730



AMF-Bruns

## SHORT OPERATION MANUAL

For vehicles with hydraulic AMF-Bruns lowering suspension



Please note: The short operation manual does not replace the regular operation manual! Please read the regular operation manual carefully before using the product.

**SHORT  
OPERATION  
MANUAL -**

*Please read carefully  
before using, and  
keep ready to hand  
inside your vehicle.*



**AMF-Bruns GmbH & Co. KG**

Hauptstraße 101 | 26689 Apen | Germany

Phone (Sale) +49 (0) 44 89 / 72 72 50

Phone (Service) +49 (0) 44 89 / 72 72 37

Fax +49 (0) 44 89 / 62 45

hubmatik@amf-bruns.de | [www.amf-bruns.de](http://www.amf-bruns.de)



[www.amf-bruns.de](http://www.amf-bruns.de)



## SHORT OPERATION MANUAL

For vehicles with hydraulic AMF-Brunns lowering suspension

### HOW TO LOWER THE VEHICLE

- Open both back doors or tail gate respectively (lowering suspension is switched on)
- Lower vehicle by switch in the vehicle's rear. The vehicle is not lowering immediately, but time-delayed due to the special cylinders filling up with oil first
- Unfold ramp

**⚠ CAUTION!**  
Don't leave back doors or tail gate respectively open for a longer period as the battery will go flat.

### HOW TO RAISE THE LOWERED VEHICLE

(Except for VW T5)

#### Vehicle with back doors

- Close left back door. The vehicle is raised automatically to travelling position
- As soon as the right back door is being closed, the lowering suspension is completely switched off, and the vehicle is ready for departure

### HOW TO RAISE THE LOWERED VW T5

- Close right back door. The vehicle is raised automatically to travelling position
- As soon as the left back door is being closed, the lowering suspension is completely switched off, and the vehicle is ready for departure



## SHORT OPERATION MANUAL

For vehicles with hydraulic AMF-Brunns lowering suspension

### HOW TO RAISE THE LOWERED VEHICLE

#### Vehicle with tail gate

**⚠ CAUTION!** For vans with tail gates the following applies: Press rocker switch in the vehicle's rear to raise the vehicle to travelling position

- Close tail gate. The lowering suspension is completely switched off, and the vehicle is ready for departure

**⚠ Any warranty work is only regulated if accepted and approved by AMF-Brunns beforehand**

For further enquiries please contact the customer services department

phone	0049 44 89 72 72 50
phone	0049 44 89 72 72 37
fax	0049 44 89 6245
email	hubmatik@amf-bruns.de